

# Component *to* **RGBHV** Converter


Operation Manual

## Features

Converts YCbCr 480i/576i and YPbPr 480p/576p signal (from NTSC/PAL DVD for example) to RGBHV input of TV or a PC monitor to view the image in high quality picture.

## Operation Controls and Functions


### Front Panel



1. Power LED.
2. Power Switch.
3. AUTO/MANU select button.
4. 480i/576i 480p/576p select button.
5. AUTO indicator.
6. 480i/576i input indicator.
7. 480p/576p input indicator.

## Operation Controls and Functions

### Rear Panel



1. Sync output select.
2. RGB output.
3. Pr/Cr Pb/Cb Y input
4. Power supply: DC 5V 2A AC 100~240V/50~60Hz.

## Specifications

### Input signal:

- 1x Y, PB/CB, PR/CR
- 3xRCA jack
- Y:1Vp-p, 75 ohm
- PB/CB: 0.7Vp-p, 75 ohm
- PR/CR: 0.7Vp-p, 75 ohm

### Output signal:

- 1x VGA
- 0.7Vp-p R,G,B 75 ohm
- 15 pin D female Connector.
- Power supply: DC 5V 2A
- Dimensions: 290(W)x 145(D)x 50(H)
- Weight: 1.2kgs

