DCT-18 L/R In-Out Lip SYNC Corrector

Operation Manual



Disclaimers

The information in this manual has been carefully checked and is believed to be accurate. Cypress Technology assumes no responsibility for any infringements of patents or other rights of third parties which may result from its use.

Cypress Technology assumes no responsibility for any inaccuracies that may be contained in this document. Cypress also makes no commitment to update or to keep current the information contained in this document.

Cypress Technology reserves the right to make improvements to this document and/or product at any time and without notice.

Copyright Notice

No part of this document may be reproduced, transmitted, transcribed, stored in a retrieval system, or any of its part translated into any language or computer file, in any form or by any means - electronic, mechanical, magnetic, optical, chemical, manual, or otherwise - without express written permission and consent from Cypress Technology.

© Copyright 2010 by Cypress Technology. All Rights Reserved. Version 1.0 August 2010

Trademark Acknowledgments

All products or service names mentioned in this document may be trademarks of the companies with which they are associated.

Safety Precautions

Please read all instructions before attempting to unpack or install or operate this equipment, and before connecting the power supply. Please keep the following in mind as you unpack and install this equipment:

- Always follow basic safety precautions to reduce the risk of fire, electrical shock and injury to persons.
- > To prevent fire or shock hazard, do not expose the unit to rain, moisture or install this product near water.
- Never spill liquid of any kind on or into this product.
- Never push an object of any kind into this product through module openings or empty slots, as you may damage parts.
- > Do not attach the power supply cabling to building surfaces.
- Do not allow anything to rest on the power cabling or allow it to be abused by persons walking on it.
- > To protect the equipment from overheating, do not block the slots and openings in the module housing that provide ventilation.

Revision History

Version No	Date	Summary of Change
VS1	20101125	Preliminary Release
VR2	20110119 5.1	Audio Specification

Table of Contents

Ι.	Introduc	ction	I
2.	Applica	ations	1
3.	Packag	ge Contents	1
4.	Feature	s	1
5.	Specific	cations	2
		nput Audio Reference Level	
6.	Operati	ion Controls and Functions	3
	6.1	Top Panel	3
	6.2	Left Panel	3
	6.3	Right Panel	3
	6.4	Front Panel	
	6.5	Rear Panel	4
7.	Connec	ction and Installation	5
8.	Acrony	m	6

1. Introduction

The L/R In-Out Lip SYNC Corrector is a compact device that corrects audio delays between audio and video. When distributing video over long distances through multiple devices like distribution amplifiers and set top boxes there can sometimes be a noticeable delay which results in audio being played before the video. This gadget lets you manually adjust the audio delay from 0 ~300 ms so you can perfectly synchronize your audio and video, so when it reaches the display your media is synched and ready to go. The Lip SYNC Corrector is an affordable and compact device that when placed beside your display greatly enhances your home audio experience.

2. Applications

- Home Theater
- Cable TV
- Set-Top-Box
- Showroom display

3. Package Contents

- Lip SYNC Corrector
- 5V / 1A Power Adaptor
- Operation Manual

4. Features

- Sample Rates 48 kHz
- Analog to analog signal bypass
- Low power consumption
- Up to 24 bit resolution

5. Specifications

Power Supply 5V / 1A DC (US/EU standards, CE/FCC/UL certified) ESD Protection Human body model: \pm 8kV (air-gap discharge)

± 6kV (contact discharge)

Dimensions(mm) 42 (W) x 40.5 (D) x 22(H)

Weight(g) 32 Chassis Material Plastic Silkscreen Color White

Operating Temperature $0^{\circ}\text{C} \sim 40^{\circ}\text{C} / 32^{\circ}\text{F} \sim 104^{\circ}\text{F}$ Storage Temperature $-20^{\circ}\text{C} \sim 60^{\circ}\text{C} / -4^{\circ}\text{F} \sim 140^{\circ}\text{F}$

Power Consumption 0.5 W


Relative Humidity 20 ~ 90% RH (non-condensing)

5.1 Input Audio Reference Level

Input Level	Output Level	THD+N	Frequence Response	SNR	Crosstalk
2 Vrms	2.0 Vrms	<0.01%	±0.5dB 20Hz~20KHz	>80dB	<-70dB


6. Operation Controls and Functions

6.1 Top Panel




① POWER LED: The LED will turn blue when the power is connected.

6.2 Left Panel




① L/R IN: These jacks are to connect with input sources such as DVD/Blu-Ray players using stereo cables in order to receive an audio signal.

6.3 Right Panel




① L/R OUT: These jacks are where you connect an output stereo cable to an amplifier, speaker or TV so you can output audio.

6.4 Front Panel



① Lip SYNC switch: This switch has eight settings that allow users to set the audio output delay from 0~300 milliseconds in order to have perfectly synched audio and video.

6.5 Rear Panel



① DC 5V: This slot is where you plug the 5V DC power supply into the unit and connect the adaptor to an AC outlet.

7. Connection and Installation



Acronyms



Acronym Complete Term

